FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF exposure statement:

The device complies with exposure to radio frequency requirements. The minimum distance between the device and the human body is 20cm.

EED WARNING

The device contains devices exempt from licence(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

The following two conditions apply:

1. The device may not cause interference, and
2. The device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes :

1. L'appareil ne doit pas produire de brouillage, et
2. L'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement. (appareils numériques de classe B)

Operating Environment: Refer to the operating conditions of the device.

REDRAGON

DRAX

Wireless LCD display controller

Wireless LCD Display Controller Operating Instructions

US/UK Multi-Function Game Controller

Operating System

Supported Platforms: Windows 10 or later / Android 8.0 or later / OS 10.14 or later / Optional

Button Description

1. Screen
2. DIRECT Button
3. Left Joystick
4. Right Joystick
5. Type-C Port
6. Left Light Trigger
7. Left Heavy Trigger
8. Turbo
9. Select
10. Left Button
11. Home
12. Right Button
13. Start
14. Right Heavy Trigger
15. Right Light Trigger
16. Y
17. X
18. B
19. A

Platform & Modes

Platform	Mode
Switch	X
Android	X
PC	X
PS4	X
PS3	X

Note:

The available user level macro information for the platforms Switch, PC, Android, and PS4 includes: Button mapping, Turbo, Dual-shock, Gyro, Joystick, Trigger, Vibration, Light, Macro, Profile, Calibration, and Firmware update.

Basic Operations

Power on & connection: Turn the power on switch on, then press and hold the HOME button for 3 seconds to enter pairing mode.

Switch: After the controller is on, the LED power is on and it will enter the HOME button pairing mode automatically.

Android: After the controller is on, the LED power is on and it will enter the HOME button pairing mode automatically.

PC: After the controller is on, the LED power is on and it will enter the HOME button pairing mode automatically.

PS4: After the controller is on, the LED power is on and it will enter the HOME button pairing mode automatically.

PS3: After the controller is on, the LED power is on and it will enter the HOME button pairing mode automatically.

Functional Operation Table

Function	Operation
Pairing	Hold HOME for 3 seconds
Sleep	Hold HOME for 6 seconds
Wake up	Press any button
Turbo	Turbo + A/B/X/Y/LB/RB/LT/RT
Dual-shock	Dual-shock + Left/Right Joystick
Gyro	Gyro + Left/Right Joystick
Vibration	Vibration + Left/Right Joystick
Light	Light + Left/Right Joystick
Macro	Macro + A/B/X/Y/LB/RB/LT/RT
Profile	Profile + 1/2/3
Calibration	Calibration + Left/Right Joystick
Firmware update	Firmware update + Left/Right Joystick

Replacement Method

CAUTION

Battery Safety Tip: Improper battery use may result in a fire, explosion or other hazard. For proper use of the battery, please follow these instructions:

- Do not open, modify or attempt to repair the battery.
- Do not expose the battery to fire, explosion or other hazardous conditions.
- Only charge the battery with the charger included in the product or a charger specifically designated for the battery.
- Do not connect the battery directly to a wall outlet or car charger.
- Do not connect the battery directly to a wall outlet or car charger.
- Do not connect the battery directly to a wall outlet or car charger